



Fast By Ferracci Inc  
1901 Davisville Rd  
Willow Grove PA 19090  
Tel (215) 657-1276  
[www.ferracci.com](http://www.ferracci.com)

## F99619 Coolant Tube Assembly Instructions

1. Start by removing the hose clamps at the top and bottom of the hose.
2. Drain the coolant out of the system. Be careful the coolant might be hot.
3. Next remove a 4 inch section from the straight part of the hose.
4. Place hose clamps over hose and insert the tube.
5. Tighten hose clamps on tube and reinstall tube on bike.
6. Tighten clamps on engine and radiators.
7. Refill coolant and start engine to be sure there are no leaks.

