

Important Notice about F56515/20

The light weight flywheel is designed for race use. It can be used on road application, but it must be loosened and retorqued, every 6000 miles (9500 Km)

Torque Specs

2000 and before	Ft-lb	N-m
4 Valve	140	190
2 valve	140	190

2001 and up		
4 Valve	190	270
2 Valve	140	190

For racing use the flywheel must be retorqued before every race.