



Fast By Ferracci Inc
1901 Davisville Rd
Willow Grove PA 19090
Tel (215) 657-1276
www.ferracci.com

F79605 50mm Fork Instructions


The compression dampening is located at the top of the fork. Use a 10mm Allen wrench to adjust it. To soften the compression dampening, turn the Allen screw out or counter clock wise. To stiffen the compression, turn the Allen screw in or clock wise. The rebound is located at the bottom of the fork, same as the compression, use a standard screw driver to soften the rebound turn the screw out or counter clock wise. To stiffen the rebound, turn the screw in or clock wise.

Warning: Do not remove or adjust the compression dampening with the screw at the top of the fork. This screw is NOT an air bleed screw.

If there are any further question or problems please contact us. If there is a problem with a fork please contact our suspension department before disassembly.

Top of fork: Compression Adjustment

Bottom of fork: Rebound Adjustment



Do not use this screw

